

1. Check the fit of the splitter to the bumper.
2. Use two screws to fix the splitter to the bumper so that one mounting hole remains free.
3. There are holes in the splitter, through which you should drill holes in the bumper.
4. Pass the bolt through the drilled hole so that the head is facing the ground.
5. Tighten the bolt firmly with the nut.
6. Remove the screws from the remaining mounting holes, and repeat steps 3-5.

